


DAL-BO

ROLLOMAX 5,30m



Brugsanvisning:

Direction for use:

Mode d'emploi:

Gebrauchsanweisung:


No. 13 900

Fra nr. 1 - 116

From no. 1 - 116

Aprés no. 1 - 116

Von No. 1 - 116



DAL-BO Automatisk tromle

Anvendelse: Før og efter såning for at sønderdele knolde og trykke sten ned.
Samtidig fås en bedre fremspiring.

TIL TROMLING PÅ MEGET LØS JORD SKAL TROMLEN VÆRE MONTERET MED 50 ELLER 55 CM RINGE.

Samling: Se fig. 4 og 5.

JUSTERINGEN AF RULLEHØJDE se fig. 1.
Husk at sidesektionerne skal monteres, så den svejste stopring vender ud mod ydersiden af tromlen.
Ved hjælp af justerskruerne (pos 1 fig. 1) justeres rullehøjden så underkant af rullen er på højde med den skrå plades nederste kant. Herved sikres, at sidesektionerne bliver på plads under transport. Husk at spænde kontra.

Tilkobling: Tromlen trækkes i traktorens svingbare trækbom. Højden af denne skal være mindst 40 cm. De to hydraulikslanger tilsluttes et dobbeltvirkende udtag på traktoren. Begge slanger er monteret med $\frac{1}{2}$ " hanstik. Hvis traktoren ikke er forberedt for dette, kan Deres forhandler hjælpe. Der kræves et maximalt pumpetryk på 160 bar. Hvis traktorens manøvreventil ikke er tætlukkende anbefales en kuglehane på slangen til cylindernes trækside. Den skal være lukket under transport.

Betjening: **NB!** TROMLEN MÅ IKKE BETJENES FØR DEN ER TILKOBLET TRAKTORENS TRÆKBOM.

Al betjening sker fra føresædet.

Udfoldningen styres ved betjening af det anvendte dobbeltvirkende hydraulikudtag med traktoren næsten i tomgang.

Slip ikke ventilhåndtaget før hjulene er hævet fri af jorden. Ved nogle traktorer vil der gå 10-15 sekunder fra tromlesektionerne når jorden, til hjulene hæves. På nogle traktorer er manøvreventilerne ikke helt tætlukkende, hvorfor det kan være nødvendigt at have hjulene med mellemrum under tromlingen.

Tromlen tåler at køre baglæns i arbejdsstilling.

Sammenfoldningen sker ved at føre hydraulikhåndtaget modsatte vej, med motoren næsten i tomgang. Kontroller at sidefløjene når helt ind til anslaget (fig. 2).

Vedligeholdelse: **SAMTLIGE MØTRIKKER** - også navmøtrikker EFTERSPÅNES efter første dags tromling.

Tromlelejerne - 6 stk - smøres for hver 50 arbejdstimer.

Chassiet - 10 smøresteder - smøres for hver 25 arbejdstimer.

Hjullejerne smøres een gang pr sæson.

Efter første sæson vil overfladen af ringene være slidt glatte og fylder derfor lidt mindre. Det opståede spillerum justeres ned til max. 5 mm ved at flytte stoppringene (se fig. 3). Husk at spænde stopskruerne godt fast. Det anbefales at løsne og spænde skruerne et par gange for at disse bedre fastner sig i akselen.

DAL-BO AUTOMATIC ROLLER

Application: Before and after sowing to break up clods and press down stones. At the same time achieving a better germination.

FOR ROLLING ON VERY LIGHT SOILS, THE ROLLER SHOULD BE MOUNTED WITH 50 OR 55 CM RINGS.

Assembly: See figs. 4 and 5.

ADJUSTMENT OF ROLLER LEVEL, see fig. 1.

Note that the wings must be mounted with the welded stop of the axle facing the outside of the roller.

With the adjusting screws (pos. 1, fig. 1) the roller level is adjusted to bring the lower edge of the roller in level with the lower edge of the inclined plate. This ensures that the lateral sections stay in position during transport. Do not forget to tighten the nuts reverse.

Coupling: The roller is drawn by the clevis drawbar on the tractor. The drawbar must be at least 40 cm high. For connection of the two hydraulic hoses, a double-acting hydraulic service on the tractor is required. Both hoses are fitted with 1/2" quick release couplings. If your tractor is not equipped for the above, your dealer can help you with this. The pump pressure required is min. 160 bar (2400 p.s.i.). If there is an internal leakage in the main valve of the tractor, it is recommended to equip the hose to the cylinder traction side with a ball valve. This must be closed during transport.

Operation: NB! DO NOT OPERATE THE ROLLER UNTIL IT HAS BEEN COUPLED TO THE DRAWBAR OF THE TRACTOR.

The hydraulic operation of the roller is accomplished from the driver's seat. The roller is unfolded using the double-acting hydraulic service with the tractor running almost idle. Do not release the control lever of the hydraulic service until the wheels are clear of the ground.

With some tractors it will take 10-15 seconds from the roller sections touching the ground and till the wheels are raised. If there is an internal leakage at the spool valves, it may be necessary to raise the wheels occasionally during work. It is also possible to back the roller in the working position. To fold the riller, move the hydraulic lever in the opposite direction with the motor running almost idle. Make sure that the lateral sections reach the stop (fig. 2).

Maintenance: ALL NUTS - including hubs - are to be TIGHTENED after the first day's work.

The roller bearings - 6 pcs. - must be greased every 50 working hours.

The cassis - 10 points - must be greased every 25 working hours.

The wheels bearings ate to be greased once every season. After the first season, the interface of the rings will be worn smooth, thus they become smaller in size. The clearance that arises due to this is adjusted down to max. 5 mm by movingthe stop rings (see fig. 3). The stop rings screws have to be tightened firmly. It is recommended to loosen and tightened firmly.

It is recommended to loosen and tighten the screws a couple of times so that they will fasten better to the shaft.

Rouleau automatique DAL-BO

Utilisation: Avant et après les semaines pour briser les mottes de terre et écraser les cailloux. En obtenant en même temps une meilleure germination.

POUR LE ROULAGE DES TERRES TRÈS LÉGÈRES, LE ROULEAU DOIT ÊTRE EQUIPÉ D'ANNEAUX DE 50 OU 55 CM.

Assemblage: Voir fig. 4 et 5.
AJUSTAGE DE LA HAUTEUR DU ROULEAU, voir fig. 1.
 Noter que les éléments latéraux doivent être montés de façon à ce que le disque d'arrêt soudé se trouve vers le côté extérieur du rouleau. A l'aide des vis de réglage (pos. 1, fig. 1) ajuster la hauteur du rouleau à ce que le bord inférieur du rouleau est au niveau du bord inférieur de la plaque oblique. Cela assure que les éléments latéraux restent en place lors du transport. N'oubliez pas de serrer les écrous de revers.

Attelage: Le rouleau est tiré par la flèche articulée du tracteur. La hauteur de celle-ci doit être 40 cm au minimum. Les deux tuyaux hydrauliques se branchent sur un seul manchon à double effet sur le tracteur. Les deux tuyaux sont équipés d'un raccord male 1/2" (12,7 mm). Si votre tracteur ne peut recevoir un tel raccord, votre revendeur est à même de vous aider. Une pression de refoulement d'au moins 160 bars est nécessaire. Si la soupape de manœuvre du tracteur n'est pas bien hermetique, nous vous recommandons de monter une soupape à boulet sur le tuyau flexible vers le côté de tirage des cylindres. Celle-ci doit être fermée lors du transport.

Fonctionnement: NB! IL NE FAUT PAS MANOEUVRER LE ROULEAU QUE QUAND IL A ÉTÉ ATTELE À LA FLECHE DU TRACTEUR.

La commande s'effectue directement à partir du poste de conduite du tracteur.
 Le dépliage est commandé par maniement du manchon hydraulique à double effet le tracteur marchant presque à vide.
 Ne relâcher le levier de commande pour le manchon hydraulique que quand les roues sont soulevées et n'ont plus d'adhérence au sol. Sur certains types de tracteurs il peut s'écouler 10 à 15 secondes entre le moment où les éléments du rouleau seront en contact avec la terre à ce que les roues soient en position relevée. Du fait que sur certains tracteurs la soupape de manœuvre n'est pas toujours bien hermetique, il sera nécessaire de relever les roues de temps à autre lors du roulage de la terre.
 Il est possible de reculer avec le rouleau en position de travail. Le repliage s'effectue par maniement du levier hydraulique en sens contraire le moteur marchant presque à vide. Il faut contrôler que les éléments latéraux arrivent à l'arrêt (fig. 2).

Entretien: L'ENSEMBLE DES ECROUS - également les écrous de moyeu - doit être RESSERRÉ après le premier jour d'utilisation.
 Les paliers du rouleau - 6 pcs. - doivent être graissés toutes les 50 heures de travail.
 Le châssis - 10 points de graissage - doit être graissé toutes les 25 heures de travail.
 Les paliers des roues doivent être graissés une fois par saison. Après la première saison la surface des disques sera légèrement usée, de ce fait ils tiendront moins de place. Le jeu qui en résulte devra être réduit à 5 mm au maximum. Ceci s'effectue en déplaçant les bagues d'arrêt (voir fig. 3). Ne pas oublier de bien serrer les vis des bagues d'arrêt. Il est recommandé de desserrer et serrer plusieurs fois les vis de façon à ce qu'elles prennent mieux sur l'axe.

DAL-BO Automatic Roller

Application: Before and after sowing to break up clods and press down stones.
At the same time achieving a better germination.

FOR ROLLING ON VERY LIGHT SOILS, THE ROLLER SHOULD BE MOUNTED WITH 50 OR 55 CM RINGS.

Assembly: See figs. 4 and 5.

ADJUSTMENT OF ROLLER LEVEL, see fig. 1.

Note that the wings must be mounted with the welded stop of the axle facing the outside of the roller.

With the adjusting screws (pos. 1, fig. 1) the roller level is adjusted to bring the lower edge of the roller in level with the lower edge of the inclined plate. This ensures that the lateral sections stay in position during transport. Do not forget to tighten the nuts reverse.

Coupling: The roller is drawn by the clevis drawbar on the tractor. The drawbar must be at least 40 cm high. For connection of the two hydraulic hoses, a double-acting hydraulic service on the tractor is required. Both hoses are fitted with 1/2" quick release couplings. If your tractor is not equipped for the above, your dealer can help you with this. The pump pressure required is min. 160 bar (2400 p.s.i.). If there is an internal leakage in the main valve of the tractor, it is recommended to equip the hose to the cylinder traction side with a ball valve. This must be closed during transport.

Operation: NB! DO NOT OPERATE THE ROLLER UNTIL IT HAS BEEN COUPLED TO THE DRAWBAR OF THE TRACTOR.

The hydraulic operation of the roller is accomplished from the driver's seat. The roller is unfolded using the double-acting hydraulic service with the tractor running almost idle. Do not release the control lever of the hydraulic service until the wheels are clear of the ground. With some tractors it will take 10-15 seconds from the roller sections touching the ground and till the wheels are raised. If there is an internal leakage at the spool valves, it may be necessary to raise the wheels occasionally during work. It is also possible to back the roller in the working position.

To fold the roller, move the hydraulic lever in the opposite direction with the motor running almost idle. Make sure that the lateral sections reach the stop (fig. 2).

Maintenance: ALL NUTS - including hubs - are to be TIGHTENED after the first day's work.

The roller bearings - 6 pcs. - must be greased every 50 working hours. The chassis - 10 points - must be greased every 25 working hours.

The wheel bearings are to be greased once every season.

After the first season, the interface of the rings will be worn smooth, thus they become smaller in size. The clearance that arises due to this is adjusted down to max. 5 mm by moving the stop rings (see fig. 3). The stop ring screws have to be tightened firmly.

It is recommended to loosen and tighten the screws a couple of times so that they will fasten better to the shaft.

Fig. 1




Fig. 2






Fig. 3



			Resevedele	Spareparts	Pieces	Ersatzteile
			=====	=====	=====	=====
			5.30m Rol-	5.30m Rol-	5.30m Rol-	5.30m Rol-
			lomax	lomax	lomax	lomax
			Fra serie	From serial	De serie	Ab Serien
			Nr. 73	No. 73	No. 73	Nr. 73
Varenr.						
Partsno.						
Numero						
Pos.	Warennr.	Dimension	Betegnelse	Designation	Designation	Bezeichnung
1	13280		Træk	Draw	Attelage	Zug
2	12270		Støtteben top	Support top	Bequille sommet	Stütze topp
3	90711	M6	Smørenippel	Nippel	Graisseur	Fett nippel
4	90687	3 mm	Hårnål	Split pin	Goupille	Sicherung
5	12224		Nagle til ben	Pin	Axe	Nagel
6	12226		Fod til ben	Foot for support	Pied de bequille	Fuss für stütze
7	12215		Støtteben cpl.	Support cpl.	Bequille cpl.	Stütze kpl.
8	92295	M12x30	Skrue	Screw	Vis	Schraube
9	92050	M12	Møtrik selv-låsende	Nut	Ecrou	Mutter gesichert
10	13281		Trækplade	Drawplate	Plaque de traction	Zugplatte
11	92338	M20x10	Bolt	Pin	Boulon	Schraube
12	92052	M20	Møtrik selv-låsende	Nut	Ecrou	Mutter gesichert
13	13285		Tårn	Tower	Tour	Turm
14	92316	M16x40	Skrue	Screw	Vis	Schraube
15	92031	M16	Møtrik	Nut	Ecrou	Mutter
16	13230		Midt sektion	Central section	Centre section	Mittel Sektion
17	13295		Nagle	Pin	Clous	Nagel
18	90711	1/8"RG 90	Smørenippel	Nipple	Graisseur	Fett nippel
19	90684	Ø8x60	Split	Split pin	Goupille	Sicherung
20	12234		Navhus	Hub housing	Moyeu	Nabengehäuse
21	12232		Navbolt	Hub pin	Moyeu noulon	Naben schraub
22	12230		Navdæksel	Hub cover	Couvercle de moyeu	Nabel decksel
23	12233		Lejesæt	Set of bearings	Jeu de roulements roue	Lagerungssatz
24	12220		Fælg	Rim	Jante	Felge
25	12222	200x14.5	Slange	Tube	Chambre à air	Schlauch
26	12221	200x14.5	Dæk 10-lags	Tyre-10 PLY	Pnue-10 PLY	Reifen-10 PLY
27	12219		Hjul cpl.	Weel cpl.	Roue cpl.	Rad cpl.
28	12231		Navmøtrik	Nut for Weel	Ecrou de roue	Radmutter
29	13225		Sidesektion	Sidesection	Lateral section gauche	Seite sektion
30	13226		venstre	left	Linker	Linker
31	13294		Sidesektion	Sidesection	Seiten sektion	Seiten sektion
32	13282		højre	right	Rechter	Rechter
33	13282		Nagle	Pin	Clous	Nagel
34	13403		Mellemlægspl.	Plate	Plaque	Platte
35	13290		Rulle	Roller	Rouleau	Rolle
36	13292		Bøjle	Bow	Collier	Bügel
37	12390	50 mm	Spændeplade	Plate	Plaque	Platte
38	92318	M16x60	Stålleje	Radial bearing	Palier	Lager
39	90011		Bolt	Pin	Boulon	Schraube
40	92383	M12	Stopring	Stop bushing	Anneau d'arrêt	Stellring
			Stopringsskrue	Stop bushing screw	Vis d'arrêt	Stellring schraube



AUG. 88

41	90012	pos 39+40	Stopring cpl.	Stop bushing cpl.	Anneau d'arrêt Stellring cpl.
42	13373	50 mm	Aksel - side	Axle	Arbre Achse
43	13374	50 mm	Aksel - midt	Axle	Arbre Achse
44	10118	45 cm	Glat tromlering	Smooth ring	Anneau lisse Glatter Ring
	10168	50 cm	Glat tromlering	Smooth ring	Anneau lisse Glatter ring
	18025	50 cm	Bølgering	Welled ring	Anneau ondule' Wellen Ring
	11019	55 cm	Knast tromlering	Cam ring	Anneau a' Nocken Ring cames
45	10119	45 cm	Takket tromlering	Jagged ring	Anneau dente Gezackter Ring
	10169	50 cm	Takket tromlering	Jagged ring	Anneau dente Gezackter Ring
46	34213		Advarsels-trekant	Warning Triangle	Signal Dreieck
47	13297		Nagle	Pin	Clous Nagel
48	13296		Nagle	Pin	Clous Nagel
49	13298		Nagle	Pin	Clous Nagel
50	92428	M24x80	Sætskrue	Screw	Vis Schraube
51	92033	M24	Møtrik	Nut	Ecrou Mutter
61	12214		Cylinder cpl.	Cylinder	Verin Zylinder
62	12225		Pakningssæt t/cylinder	Set of sealings	Jeu de joints Dichtung
63	12251		Stempel	Piston	verin für Zylinder Kolben
64	12252		Stempelstangs føring	Cylinderhead-bushing	Douille de tige de piston Buchse für Kolbenstang
65	12253		Stempelstang	Piston pin	Tige de piston Kolbenstange
66	12271		Stempel-stangsøje	Piston pin head	Tete pour tige Kolbensange-de piston kopf
67	60213		Cylinder cpl.	Cylinder	Verin cpl. Zylinder
68	12273		Pakningssæt t/cylinder	Set of sealings	Jeu de joints Dichtung
69	13310		Slange cpl.	Tube cpl.	Tuyau cpl. Schlauch kpl.
70	13311		Slange cpl.	Tube cpl.	Tuyau cpl. Schlauch kpl.
71	13312		Slange cpl.	Tube cpl	Tuyau cpl. Schlauch kpl.
74	91002	3/8"x3/8"	Brystnippel	Adapter	Raccord hyd.d. Verschraubung
75	91033	Ø22xØ17	Kobberskive	Copper washer	Rondelle en Kupfer schreibe
76	91001	M22x3/8"	Brystnippel	Adapter	Raccord hyd.d. Verschraubung
77	91034	Ø27/Ø22	Kobberskive	Copper washer	Rondelle en Kupfer schreibe
78	12228	3/8"	Drøvle-kontraventil	Restrictor valve	Soupape a etrangement Drosselrück-schlagventil
79	91006	M18	T-stykke	T-piece	T-piece T-stück
80	91012		Blændhætte	Cover	Couvercle Staukappe
81	91010	1/2"	Lynkobling hanpart	Oil connection male	Valve male Ølanschluss
82	91038		O-ring	O-ring	push pull male
83	13313		Slange cpl.	Tube cpl.	O-anneau O-Ring
85	12256		Slangeholder	Tube Fastener	Tuyau cpl. Schlauch halter
86	92401		Galopskrue	Screw	Pin Schraube
87	92027	M6	Møtrik	Nut	Ecrou Mutter
88	13315		Drøvling	Trusch	Grive Drossel
89	91078		Lige forskru-nning	Straight nippel	Droit raccord Gerade Nippel




FIG. 88

